

SOUTHERN COMPANY DISTRIBUTION INTERCONNECTION POLICY

Inverter Based Generators 25 kW and Smaller

This document contains the interconnection requirements for inverter based generators, 25 kW and smaller, that operate in parallel with the Southern Company's distribution system.

December 1st, 2013

Effective Date: December 1, 2013

TABLE OF CONTENTS

	<u>Page</u>
1.0 INTRODUCTION	3
1.1 Purpose	3
1.2 Scope	3
1.3 Safety	
2.0 RIGHT TO DISCONNECT	4
3.0 MODIFICATIONS TO COMPANY OR CUSTOMER FACILITIES	5
4.0 CUSTOMER RESPONSIBILITIES	5
4.1 Operations and Maintenance	5
4.2 Energizing Dead Circuits	5
5.0 REFERENCES	5
APPENDIX A METERING ARRANGEMENTS	6
APPENDIX B APPLICATION	7
APPENDIX C INTERCONNECTION REQUIREMENTS	8
APPENDIX D. DEFINITIONS	۵



Effective Date: December 1, 2013

1.0 Introduction

Customer owned generators may be operated in parallel with the Southern Company ("Company") distribution system pursuant to an Interconnection Agreement, provided that the generator and Interconnection Equipment meets the requirements of this policy, subject to all applicable statutory and regulatory requirements.

1.1 Purpose

This policy sets forth the minimum interconnection requirements, application process and procedures for connection and safe operation of generators in parallel with the Company's distribution system.

1.2 Scope

This document sets forth the requirements for interconnection of Customer owned, single and three phase inverter based generation equipment, up to an aggregate of 25 kW alternating current (ac), based on the nameplate(s), that operates in parallel with the Company's distribution system. Connections will be at the available service voltage.

The rules of Federal, state or local regulatory agencies shall take precedence over these requirements. If this document does not comply with any federal state or local regulation, then this document is superseded by the applicable regulation.

1.3 Safety

The safety of the general public, Company employees and equipment shall in no way be reduced or impaired as a result of the interconnection. In general, the Customer's facilities will be held to the same standard of care that the Company is required to maintain.



Effective Date: December 1, 2013

1.4 Application Process

The steps in the process to interconnect a generator to the Company distribution system are:

- **1.** Contact the Company designated representative and request interconnection information, including rules, rate options, guidelines and an application.
- **2.** Complete the application form, including information about the proposed system and send it to the Company representative.
- 3. After review and approval of the application, installation may begin. Once the installation is complete, contact the Company representative to let him/her know your installation is complete.
- **4.** Sign the contract and/or an Interconnection Agreement.

2.0 Right to Disconnect

The Company may disconnect generation equipment from the distribution system for any of the following conditions:

- 1. Expiration, termination or lack of interconnection agreement.
- 2. Non-compliance with the technical requirements.
- System emergency.
- 4. Situations when continued interconnection will endanger persons or property.
- 5. Routine or emergency maintenance, repairs, or modifications to the distribution system.
- 6. Failure of Customer to comply with any existing or future regulations, rules, orders or decisions of any governmental or regulatory authority having jurisdiction over the Customer's electric generating equipment or the operation of such equipment, which failure of compliance would place in jeopardy the personnel, or property, or service capability of the Company, or would pose a threat of sanction or liability to the Company in the event that it continued interconnection.
- 7. Adverse effect of Customer's generation to the Company's other electric consumers and/or system as determined by the Company.



Effective Date: December 1, 2013

3.0 Modifications to Company or Customer Facilities.

The Customer may be responsible for the cost of modifications that must be made by the Company on its distribution system.

4.0 Customer Responsibilities

4.1 Operations and Maintenance

The customer is solely responsible for proper operation of the customer's generation facilities.

4.2 Energizing Dead Circuits

The Customer shall not energize a de-energized Company distribution circuit.

5.0 References

UL 1741 – 2010, UL Standard for Inverters, Converters, Controllers and Interconnection System Equipment for Use with Distributed Energy Resources.

IEEE Std. 1547-2003, IEEE Standard for Interconnecting Distributed Resources with Electric Power Systems.

Note: Where a later version of a standard exists, the current version will apply.




Generator

Title: Inverter Based Generators 25 kW and Smaller

Effective Date: December 1, 2013

Appendix A Metering Arrangements

Category 1 Customer exports excess Electric System METER • Power delivered • May include power received Load





Effective Date: December 1, 2013

Appendix B Application

The generator owner shall complete the application for providing the generator data on the applicable form.

Application – Generator, Service Point and Requestor Information
Customer Name (as shown on Company account):
Company Account Number at Service Point where Generator will be Located
Service Point Street Address:
Service Point City, State, Zip:
Inverters to be connected to Company.
Please list all the inverters / generators that will be interconnected to Company. For equipment ratings, please use the nameplate rating found on the equipment or in the equipment specifications.
Inverter(s) / Generator(s) Manufacturer
Inverter(s) / Generator(s) Model No:
Inverter(s) / Generator(s) Nameplate Rating (kW)
Inverter(s) / Generator(s) Output Voltage Rating:
Single Phase Three Phase
Does Inverter / Generator meet the requirements of UL Standard 1741?
Number of proposed Inverter(s) / Generator(s) of this type
Expected Generator Start-up Date:
Comments:



Effective Date: December 1, 2013

Appendix C Interconnection Requirements

C.1 General Interconnection Requirements

The Customer's generation facilities shall meet the technical requirements as prescribed in this Appendix. The Company reserves the right to impose additional requirements as necessary; additional requirements will be made a part of the interconnection agreement.

C.2 Customer's Equipment and Interconnection Standards

The Customer's generation and interconnection installation must meet all applicable federal, state, and local construction and safety codes.

The Customer shall be responsible for the design, installation, operation and maintenance of all equipment and facilities installed or that will be installed on the Customer's side of the point of interconnection. Such design shall meet the requirements of UL 1741, the NEC, other national codes and any local codes pertaining to the design and construction of electrical facilities. The facility shall be subject to the requirements of all authorities having jurisdiction and shall comply with all applicable codes and ordinances.

C.3 Protection of Customer's Equipment

The Customer will be responsible for protecting its generating equipment in such a manner that distribution system outages, short circuits or other disturbances do not damage the Customer's generating equipment.

C.4 Voltage Regulation

Unless otherwise specified by the applicable regulatory authority, the Customer will operate his generating equipment within the ranges specified by ANSI C84.1 Table 1, Range A, measured at the point of interconnection. On a 120 volt basis, this range is 114-126 volts.

C.5 Requirements for Units 25 kW or Less

Inverter based units shall be marked as meeting the requirements of UL 1741.

C.6 Metering Requirements

Appendix A outlines two metering arrangements utilized by the Company. Net metering is prohibited unless provided for by state law or regulation.



Effective Date: December 1, 2013

Appendix D Definitions

<u>Company</u> –The Southern Company operating subsidiary to which the Customer is requesting interconnection.

<u>Customer</u> - Customer, its agent, partner or other entity located on the customer's premise connected to the Company's distribution system for the purpose of receiving and/or exporting electric power through the Company's distribution system.

<u>Distribution System</u> – The Company's wires, equipment and facilities, with a voltage 34.5 kV and below, to which the generation equipment is interconnected.

<u>Interconnection Agreement</u> – The document that sets forth the contractual conditions under which the Company and a Customer agree that a facility may be interconnected with the Company's distribution system.

<u>Interconnection Equipment</u> - All equipment installed solely to interconnect and exchange power between the Customer's generation facility and the Company's distribution system.

<u>Parallel Operation</u> - The operation of electric generation connected to the utility electric distribution system.

<u>Point of Interconnection</u> - The point of connection of the Customer's service equipment to the utility electric system.

<u>Power Delivered</u> – energy supplied by the utility to the Customer (generator owner).

<u>Power Received</u> – energy supplied by the Customer (generator owner) to the utility.

<u>Southern Companies or Southern Company</u> - collectively, Alabama Power Company, Georgia Power Company, Gulf Power Company, and Mississippi Power Company.